



Ridge Clip

Ridge clip (S)



[For 12mm,14mm,16mm Rod]

Ridge clip (M)



[For 18mm,20mm,23mm Rod]

Ridge clip (L)



[For 25mm,28mm,33mm Rod]

Benefits:

- Protects the scalp from heat during the perm procedure.
- The combination of Anti-Heat pad, Rod clip and Rod pad, facilitate the perm procedure.
- The Ridge Clips are able to hold the rods closer to the scalp therefore creating more body at the root.
- Can be used with all types of rods (12mm ~33mm) and therefore suitable for short hair or long hair.

How to use Ridge Clip

1) Take a section of hair and wind onto rod, do not wind all the way down to the root.



2) Place the anti-heat pad section of the ridge clip on the underside of the rod, then continue to wind hair onto the rod towards the ridge clip so that the rod is covered by the anti-heat pad.



3) Secure rod with the ridge clip.

4) Connect rod to the Digital Perm Machine via the rod lines and select appropriate heat setting.



How to take off Ridge Clip

1) Once the thermal process is complete, allow rods to cool before removing the ridge clip.



2) Once ridge clip is removed, ensure hair is secure around the rod and wind to the root.



3) Secure rod with an Anti-Heated Rubber Band, and leave hair to completely cool for 2-3 minutes. Once cool, apply lotion No.2

